



REMOTE CONTROL INSTRUCTIONS



- SELECT MOVIE [A. Move Cursor - Mouse
- [B. Select Movies & Links - Left Mouse key
- [C. Move Page Up & Down - Page Up / Page Down key
- WATCH MOVIE [D. Back to Main Movie Page - Tab key
- [E. Full Screen - Windows key
- [F. Play / Pause - Enter key
- [G. Exit Full Screen - ESC key



Arabic TV

1. Stop Video
2. Volume Up/Down
3. Mute
4. Enter/Select Channel On Guide
5. Select/Move Left On Guide
6. Select/Move Down On Guide
7. Page Up/Down On Guide
8. Select/Move Up On Guide
9. Full Screen On/Off
10. Select/Move Right on Guide
11. Stop Video

