



# Remote Control Functions

This is the “Full Screen” key.  
Do NOT press it to choose a channel.

This is the “Enter” key.  
You MUST press it to choose a channel.